



Blinder MOB

QUICKSTART GUIDE

RECHARGE BEFORE FIRST USE




USB Plug



USB Plug

* Standard model shown


INTERFACE



- A. Low Battery Indicator
- B. Power / Mode switch
- C. Recharge Indicator

Long press B to turn light on and off. Short press B to cycle between modes.

V INTERFACE



- A. Recharge Indicator
- B. Power / Mode switch
- C. Low Battery Indicator

Long press B to turn light on and off. Short press B to cycle between modes.

FITMENT

FRONT LIGHT

2 STRAPS & 1 CLASP INCLUDED

- 1. SML: Ø 22-27MM
- 2. MED: Ø 27-32MM



REAR LIGHT & V

3 STRAPS & 1 CLASP INCLUDED

- 1. SML: Ø 22-27MM
- 2. MED: Ø 27-32MM
- 3. LRG: Ø 32+MM*



* Suitable for most aero posts

INTERCHANGEABLE STRAP



Stretch strap to fit clasp



Place strap end over hook



Pull strap toward the light body

MOUNTING



- 1. Pull silicone strap around bar
- 2. Engage latch into hook

STORAGE MODE



Light can be placed in storage mode if not used for a long time. To activate, make sure the light is turned off & then hold the button (B) for 5 seconds to begin. The Low Battery Indicator light (A) will turn on to show mode is active and in storage. User's can exit storage mode at any time with any press of the button. As always, the light should be charged before running storage mode.

THE MOB

The Blinder MOB range is available in Front, Rear and Vertical lights. (Eyeballer excluded.)



Eye Baller



Four Eyes



The Face



Kid Grid



Mr Chips