







PLUG QUICK START



CHARGING

Charge before first use. Open silicone cover to expose the USB port. Connect to a computer using a standard Micro USB cable. If using a power outlet, use only suitable USB chargers. Charge indicator glows red when charging.

MOUNTING FRONT LIGHT

Attach strap to the rear mount band channel and stretch around to the front hook. (S & M straps included).

MOUNTING REAR LIGHT

Attach strap to one side hook and stretch around the other side hook. (S, M & L straps included).

FRONT LIGHT OPERATION

Press and hold power button (back of light) to turn on/off the light. Fast press to change modes. LBI (visible through lens and LHS side window) stays on for 2 seconds after turning off, when the battery is low.

REAR LIGHT OPERATION

Press and hold power button (underneath Plug Rear) to turn on/off the light. Fast press to change modes. LBI (visible through lens and LHS side window) stays on for 2 seconds after turning off, when the battery is low.